Workhorse Plus Table Top 47”

Finished Product



Detail View Back

Detail View Front



Step 1. Flip the base upside down and rotate the feet to sit perpendicular to the aluminum base with the narrow ends pointing to the back of the base.



Included Pieces:
1. Padded Carrying Bag
2. Aluminum Base
3. Banner Rail
4. 2 Telescoping Shock Cord Poles
5. Banner Locking Pin

Step 2. Flip open the lock to release the telescoping poles. Push the lock closed to secure the poles in place.

Step 3. Place the assembled poles into the aluminum base on the floor.

Step 4. Pull the attached banner rail upwards to meet the top of the assembled poles.

The banner should not exceed 43 inches. Do not abruptly release the banner from its full height, it will cause the banner to snap down and break.
Store in a cool, dry location.

Step 5. Attach the banner rail to the top of the assembled poles. Unlock each pole and slide the top section upwards or downwards to adjust to the desired height. Re-lock the poles to keep the height.

We are unable to accept returns on personalized promotional products, except in the case of manufacturing defects.
We require that you check your order for defects immediately. There are absolutely no returns after 60 days from the receipt of your order.
Please contact our Customer Care Department in the event you receive defective merchandise. We will work diligently to resolve your issue.